

Dreambox 500 Setting for Multiswitches EMP-Centauri P.160 / P.170 series

P.160 (MS13) series

LNB 1

1	Toneburst :	no
2	DiSEqC mode :	Version 1.0
3	DiSEqC Parameter :	A/A
4	DiSEqC Repeats :	no
5	Uncommitted switch :	no
6	Sequence repeat :	no
7	Swap Commands :	no
8	Fast DiSEqC :	no

LNB 2

1	Toneburst :	no
2	DiSEqC mode :	Version 1.0
3	DiSEqC Parameter :	A/B
4	DiSEqC Repeats :	no
5	Uncommitted switch :	no
6	Sequence repeat :	no
7	Swap Commands :	no
8	Fast DiSEqC :	no

LNB 3

1	Toneburst :	no
2	DiSEqC mode :	Version 1.0
3	DiSEqC Parameter :	B/A
4	DiSEqC Repeats :	no
5	Uncommitted switch :	no
6	Sequence repeat :	no
7	Swap Commands :	no
8	Fast DiSEqC :	no

P.170 (MS17) series

LNB 1

1	Toneburst :	no
2	DiSEqC mode :	Version 1.0
3	DiSEqC Parameter :	A/A
4	DiSEqC Repeats :	no
5	Uncommitted switch :	no
6	Sequence repeat :	no
7	Swap Commands :	no
8	Fast DiSEqC :	no

LNB 2

1	Toneburst :	no
2	DiSEqC mode :	Version 1.0
3	DiSEqC Parameter :	A/B
4	DiSEqC Repeats :	no
5	Uncommitted switch :	no
6	Sequence repeat :	no
7	Swap Commands :	no
8	Fast DiSEqC :	no

LNB 3

1	Toneburst :	no
2	DiSEqC mode :	Version 1.0
3	DiSEqC Parameter :	B/A
4	DiSEqC Repeats :	no
5	Uncommitted switch :	no
6	Sequence repeat :	no
7	Swap Commands :	no
8	Fast DiSEqC :	no

LNB 4

1	Toneburst :	no
2	DiSEqC mode :	Version 1.0
3	DiSEqC Parameter :	B/B
4	DiSEqC Repeats :	no
5	Uncommitted switch :	no
6	Sequence repeat :	no
7	Swap Commands :	no
8	Fast DiSEqC :	no