

Dreambox 500 Setting for Switch EMP-Centauri P.168 (P.168-W, P.180)

version 1

(INP 1 labeled „com A, uncom A“, see sticker)

LNB 1

1	Toneburst :	no
2	DiSEqC mode :	Version 1.1
3	DiSEqC Parameter :	A/A
4	DiSEqC Repeats :	no
5	Uncommitted switch :	Input 1
6	Sequence repeat :	no
7	Swap Commands :	no
8	Fast DiSEqC :	no

LNB 2

1	Toneburst :	no
2	DiSEqC mode :	Version 1.1
3	DiSEqC Parameter :	A/B
4	DiSEqC Repeats :	no
5	Uncommitted switch :	Input 1
6	Sequence repeat :	no
7	Swap Commands :	no
8	Fast DiSEqC :	no

LNB 3

1	Toneburst :	no
2	DiSEqC mode :	Version 1.1
3	DiSEqC Parameter :	B/A
4	DiSEqC Repeats :	no
5	Uncommitted switch :	Input 1
6	Sequence repeat :	no
7	Swap Commands :	no
8	Fast DiSEqC :	no

LNB 4

1	Toneburst :	no
2	DiSEqC mode :	Version 1.1
3	DiSEqC Parameter :	B/B
4	DiSEqC Repeats :	no
5	Uncommitted switch :	Input 1
6	Sequence repeat :	no
7	Swap Commands :	no
8	Fast DiSEqC :	no

LNB 5

1	Toneburst :	no
2	DiSEqC mode :	Version 1.1
3	DiSEqC Parameter :	A/A
4	DiSEqC Repeats :	no
5	Uncommitted switch :	Input 2
6	Sequence repeat :	no
7	Swap Commands :	no
8	Fast DiSEqC :	no

LNB 6

version 2

(INP 1 labeled „uncommitted 1“, see sticker)

LNB 1

1	Toneburst :	no
2	DiSEqC mode :	Version 1.1
3	DiSEqC Parameter :	none
4	DiSEqC Repeats :	no
5	Uncommitted switch :	Input 1
6	Sequence repeat :	no
7	Swap Commands :	no
8	Fast DiSEqC :	no

LNB 2

1	Toneburst :	no
2	DiSEqC mode :	Version 1.1
3	DiSEqC Parameter :	none
4	DiSEqC Repeats :	no
5	Uncommitted switch :	Input 2
6	Sequence repeat :	no
7	Swap Commands :	no
8	Fast DiSEqC :	no

LNB 3

1	Toneburst :	no
2	DiSEqC mode :	Version 1.1
3	DiSEqC Parameter :	none
4	DiSEqC Repeats :	no
5	Uncommitted switch :	Input 3
6	Sequence repeat :	no
7	Swap Commands :	no
8	Fast DiSEqC :	no

LNB 4

1	Toneburst :	no
2	DiSEqC mode :	Version 1.1
3	DiSEqC Parameter :	none
4	DiSEqC Repeats :	no
5	Uncommitted switch :	Input 4
6	Sequence repeat :	no
7	Swap Commands :	no
8	Fast DiSEqC :	no

LNB 5

1	Toneburst :	no
2	DiSEqC mode :	Version 1.1
3	DiSEqC Parameter :	none
4	DiSEqC Repeats :	no
5	Uncommitted switch :	Input 5
6	Sequence repeat :	no
7	Swap Commands :	no
8	Fast DiSEqC :	no

LNB 6

1 Toneburst : no
2 DiSEqC mode : Version 1.1
3 DiSEqC Parameter : A/B
4 DiSEqC Repeats : no
5 Uncommitted switch : Input 2
6 Sequence repeat : no
7 Swap Commands : no
8 Fast DiSEqC : no

LNB 7

1 Toneburst : no
2 DiSEqC mode : Version 1.1
3 DiSEqC Parameter : B/A
4 DiSEqC Repeats : no
5 Uncommitted switch : Input 2
6 Sequence repeat : no
7 Swap Commands : no
8 Fast DiSEqC : no

LNB 8

1 Toneburst : no
2 DiSEqC mode : Version 1.1
3 DiSEqC Parameter : B/B
4 DiSEqC Repeats : no
5 Uncommitted switch : Input 2
6 Sequence repeat : no
7 Swap Commands : no
8 Fast DiSEqC : no

1 Toneburst : no
2 DiSEqC mode : Version 1.1
3 DiSEqC Parameter : none
4 DiSEqC Repeats : no
5 Uncommitted switch : Input 6
6 Sequence repeat : no
7 Swap Commands : no
8 Fast DiSEqC : no

LNB 7

1 Toneburst : no
2 DiSEqC mode : Version 1.1
3 DiSEqC Parameter : none
4 DiSEqC Repeats : no
5 Uncommitted switch : Input 7
6 Sequence repeat : no
7 Swap Commands : no
8 Fast DiSEqC : no

LNB 8

1 Toneburst : no
2 DiSEqC mode : Version 1.1
3 DiSEqC Parameter : none
4 DiSEqC Repeats : no
5 Uncommitted switch : Input 8
6 Sequence repeat : no
7 Swap Commands : no
8 Fast DiSEqC : no